Tube Coil Pick-up and Pay-out Trailer BRT 20





The BRT 20 is able to pick up, load and uncoil pipe coils without any help. Even laying coils can be picked up without any auxiliary equipment. Tube coils of varying diameters may be picked up with the aid of the vertical hydraulic jacks and put down on the bearing rollers. Then three guiding rollers are inserted on the inside of the coil, and the coil is ready for unreeling.



Since the coils are picked up from the rear, all hydraulic control levers are arranged at the rear. The operator's stand within the slewing range of the pick-up frame is provided with a protection guard.

Even coils lying flat on the ground can be picked up by the frame and slewed into the roller cage.

The pick-up shaft runs on bearings and is provided with spherical ends, which prevent the shaft from being stressed irrespective of the relative position of the lifting arms.

During tube unreeling two steadying wheels hold the narrow coils (100 m length) in centre position.

Attention: The inner end of the pipe has to be cut flush to the pipe coil!

Techniacl Data:

Type	Pay- load	Total Weight	Max. Drum dia.	Loading Width	Chassis		Length mm	Width mm	Height mm	Order No.
	kg	kg	mm	mm	Type	Brake				
BRT 20	1800	3500	3700	1500	700	overrun	5850	2500	3050	038.250.00

Specifications are subject without notice. Output details are depending on use conditions.



S_1-20_Rubrik_6_englisch.indd 17 01.10.12 12:45